


## GaugeCam:


An Image-Based System to Measure Water Levels in Streams

Troy Gilmore, François Birgand,  
Kenneth Chapman, Andrew Brown


## Can we detect water level?




## Can we *measure* water level?



## The System: Edge Detection



## The System: Edge Detection



## The System: Edge Detection




## The System: Edge Detection



## The System: Calibration



## The System: Calibration




## Lab Research Objective:

Quantify source and magnitude of uncertainty when measuring water level with images

## Uncertainty: Sources

1. Image Resolution
2. Lighting effects
3. Perspective
4. Lens distortion
5. Water meniscus

## Uncertainty: Three Experiments




## Uncertainty: Three Experiments


### Benchmark I

1. Image Resolution
2. Lighting effects
3. Perspective
4. Lens distortion
5. Water meniscus


## Uncertainty: Benchmark I



## Uncertainty: Benchmark I




## Uncertainty: Benchmark I




## Uncertainty Calculation

- Many images per resolution
- Error = measured – known value
- Calculated distribution of errors for each resolution
- Calculated bias, SD and RMSE of each distribution

## Benchmark I: RESULTS



## Benchmark I: RESULTS




## Uncertainty: Three Experiments

Benchmark I



Benchmark II

1. Image Resolution
2. Lighting effects
3. Perspective
4. Lens distortion
5. Water meniscus


## Benchmark II



## Uncertainty: Sources



## Benchmark II: RESULTS





# Uncertainty: Three Experiments



Benchmark I

Benchmark II


Water Level

1. Image Resolution
2. Lighting effects\*
3. Perspective
4. Lens distortion
5. Water meniscus

## Uncertainty: Camera effects




## Water Level: Posture Angle



For camera at 6 meters

## Water Level: 6m, 16mm lens



## Conclusions

1. Lens distortion must be minimized
2. Posture angle may interact with meniscus
3. With reasonable precautions, accuracy of  $\pm 3$  mm (0.01 ft) is achievable in the lab

## Acknowledgements

Salt Marsh Images:  
Randall Etheridge, Brad Smith

Lab Analysis Assistance:  
Kelly Chapman

Camera Equipment:  
[www.Microseven.com](http://www.Microseven.com)  
[www.Colorado-Video.com](http://www.Colorado-Video.com)

Software:  
[www.GaugeCam.com](http://www.GaugeCam.com)

**Check out our ASABE 2011 booth!**



Louisville Belle waterline